

- Using Unistrut Nuts (0-79083-100), bolt C-Track Hangers (06000) to Unistrut Brackets (06021). Place the pendant track hanger at the end of the bracket, and the hoist festooning track hanger about 6"-8" in from the end.
- Mount assembled brackets to beam with supplied hardware (Items 11, 12, & 13) utilizing pre-drilled holes in the beam web.
- Slide the C-Track (06008 or 06009) into the hangers. Start at one end of the system. Install Track Couplers (06001) (if required) as you proceed, as they will support the adjacent section of track. After all track and hangers are in place, tighten hanger retaining hardware.
- Install a Flat Cable End Clamp (06003) on the mast end of each C-Track.
- Install selected number of Cable Trolleys (06004) into each C-Track. If it is convenient, cable may be installed into trolleys on the floor, establishing the correct loops and tie wrapping as required.
- Install the Towing Trolley (06005) into the hoist festoon track (closer to beam), and the Pendant Trolley (06006) into the pendant track (outer track). This may also be assembled on the floor, if convenient.
Alternate: Mount all trolleys for one side in one length of track. Assemble cable to trolleys, lift into place. Repeat for the opposite side.
- Install a Hanger Endstop (06002) on open end of each C-Track.
- Remove any extra track with a fine tooth hacksaw.
- Connect cables to junction boxes or enclosure as needed.

ITEM	PARTNUMBER	DESCRIPTION
1	06000	C-TRACK HANGER
2	06001	COUPLER W/HDW
3	06002	HANGER ENDSTOP
4	06003	FLAT CABLE END CLAMP
5	06004	FLAT CABLE TROLLEY
6	06005	FLAT CABLE TOW TROLLEY
7	06006	PENDANT TROLLEY
8	06008 / 06009	C-TRACK, 13' OR 20'
9	06021	UNISTRUT BRACKET, 24"
10	0-79083-100	UNISTRUT NUT, 3/8-16
11	02026	HHCS 1-2"-13 X 1.5" LG
12	03291	LOCKWASHER, 1/2"
13	03289	HEXNUT, 1/2"-13
14	VARIES	HOIST FESTOONING
15	VARIES	PENDANT FESTOONING
16	VARIES	JIB BOOM

